

PRODUCT MANUAL



MNX10080, REV A.DOCX • 11/17/2016

CONTENTS

SECTION 1: OVERVIEW	4
Introduction	4
Product Selection Guide	4
Specifications	5
Environmental	5
Physical	5
SECTION 2: OPERATION	3
Operating Procedure	6
SECTION 3: TROUBLESHOOTING.	10
SECTION 4: MAINTENANCE	11
Maintenance	11
General	11
Warranty	11

FIGURES

Figure 1 - Product Selectin Guide	4
Figure 2 - Housing Dimensions	
Figure 3 - Probe installation into Sleeve	6
Figure 4 - Sleeve installation into housing	6
Figure 5 - Extension cable installation	
Figure 6 - Gap Adjustment	7
Figure 7 - Coupling Nut	8
Figure 8 - Hex Nut	
Figure 9 - Lid Installation	
Figure 10 - Completed Installation	

Introduction

This document contains information on the operation, installation and maintenance of the reverse mount proximity probe housing. The PRO DM91000 series housing protects important proximity probe instruments in harsh manufacturing conditions. Easily adjust the gap between the machine shaft and probe or replace an extension cable without shutting down a machine.

Product Selection Guide




Figure 1 - Product Selectin Guide

Specifications

Environmental

Temperature Range: -31°F(-35°C) to 350°F(177°C)

Physical

Materials:

Housing Aluminum Sleeve 316L SST




Figure 2 - Housing Dimensions

Mounting Instructions

- 1. Mount base onto machine via ¾-14 NPT mounting thread.
- 2. Insert reverse mount probe into SST sleeve.



Figure 3 - Probe installation into Sleeve





Figure 4 - Sleeve installation into housing

4. Run Extension cable into housing thought one of the two ¾-14 NPT ports.



5. Gap probe by adjusting the sleeve nut.




Figure 6 - Gap Adjustment

6. Tighten down coupling nut onto probe.



Figure 7 - Coupling Nut

7. Tighten down hex nut onto coupling nut.



Figure 8 - Hex Nut

8. Bundle cable and push into lid.




Figure 9 - Lid Installation

9. Tighten down lid onto housing.



Figure 10 - Completed Installation

MNX10080, REV A.DOCX • 11/17/2016

SECTION 3: TROUBLESHOOTING

Note: For specific problem resolution, please call an Applications Engineer at 1-800-999-5290.

SECTION 4: MAINTENANCE

Maintenance

Once the DM91000 housing has been installed, minimal maintenance will be required. Basic visual checks to ensure integrity should be made periodically.

General

There are no customer replaceable parts. The DM91000 housing has been designed for trouble – free service under normal operating conditions.

Warranty

If any PRO product should ever fail, we will repair or replace it at no charge, as long as the product was not subjected to misuse, natural disaster, improper installation or modification which caused the defect.